

SAFETY NOTICE

READ BEFORE ASSEMBLY AND USE

V1.2 - NOVEMBER 2024

MAIN INFORMATION

1 General

1.1 Introduction This user manual contains important information on handling the product.

To ensure safe use of the product, read the user manual carefully and follow the safety instructions.

La Tablette Française reserves the right to change product specifications without notice.

Before reading this document, make sure you have the most recent version.

This version is available in PDF format on the La Tablette Française website.

In the event of a serious incident with the product, you must inform the manufacturer and the competent authority in your country.

1.2 Warranty information

We provide a manufacturer's warranty for the product (excluding wear parts), in accordance with our general terms and conditions of sale in force in the various countries. Warranty claims can only be made to the supplier from whom the product was obtained.

1.3 Compliance

We only use materials and components that comply with the REACH regulation.

This product bears the CE mark

We are constantly striving to minimise our impact on the environment, both locally and globally.

1.4 Lifespan:

The expected life of this product is three years when used daily and in compliance with the safety instructions, maintenance intervals and with correct use, as indicated in this manual. The actual life may vary depending on the frequency and intensity of use.

1.5 Limitation of liability

La Tablette Française declines all liability in the event of damage related to:

- failure to comply with the user manual,
- incorrect use,
- normal wear and tear,
- incorrect assembly or mounting by the purchaser or third parties,
- technical modifications,
- unauthorized modifications and/or the use of unsuitable spare parts.

1.6 Cleaning

Unsuitable methods or liquids may cause injury or damage to the product.

- All disinfectants and cleaning agents used must be effective, compatible with each other and protect the surfaces they are intended to clean.
- Never use corrosive (alkaline, acidic, etc.) or abrasive cleaning agents. We recommend using a regular household cleaning agent, such as dishwashing liquid, unless otherwise specified in the cleaning instructions.
- Never use solvents (cellulose thinner, acetone, etc.) which alter the structure of the plastic.
- Dry the product thoroughly before using it again.

Regular disinfection and cleaning ensure proper functioning, increase the service life and prevent contamination. Clean and disinfect the product:—regularly during use,—before and after any maintenance procedure,—when it has been in contact with bodily fluids of any kind,—before using it for a new user.

Maximum cleaning temperature: 60°C by hand.

1. Remove removable parts.
2. Clean the product, wipe all generally accessible surfaces.
3. Wipe the parts with a dry cloth.

1.7 Disposal

Please protect the environment by having this product recycled at the end of its life at a recycling centre.

Disassemble the product and its components so that the different materials can be separated and recycled individually.

Disposal and recycling of used products and packaging must comply with the laws and regulations on waste management in each country.

Contact your local waste management organisation for more information.

WARNING AND SAFETY

• Risk of property damage or serious injury if you do not follow the provided installation instructions. Improper use of this product may result in personal injury or property damage.

• If you do not understand the warnings, cautions, or instructions, contact your supplier before attempting to use this equipment.

• Do not use this product or any optional equipment without completely reading and understanding these instructions and any additional instructional documentation, such as the user manual, maintenance manuals, or instruction sheets provided with this product or optional equipment.



WARNINGS

- Do not use the product if it is defective
 - Do not make any unauthorized modifications or alterations to the product.
 - Do not move the product while it is loaded or in use.
 - The product must not be used or stored outdoors.
 - Do not tilt the product.
 - Do not sit on the product.
 - Before using the product for the first time, clean it thoroughly.
 - Before each use, make sure that the product is not damaged and that it is correctly assembled.
 - Unsuitable or non-original parts may affect the function and safety of the product.
 - Only use original parts for the product used.
 - In case of regional differences, you must refer to the website for available options or contact your supplier.
 - Risk of falling
 - Risk of trapping fingers
 - Proceed with caution during assembly.
- Risk of product damage:
- Plastic parts may crack when screws are overtightened.
 - Tighten screws by hand.
 - The felt sticker under the rotating tablet is not covered by the warranty (available as a replacement spare part).



LA TABLETTE FRANÇAISE®

THE FRENCH TAB



www.latablettefrancaise.fr